


THE TRANSMITTER

1. Synchronization
2. Mute
3. Microphone connector
4. Battery charge level indicator
5. Mute indicator/ built-in microphone
6. Charger connector
7. Built-in microphone




THE RECEIVER

1. Volume up
2. Volume down
3. Earphone connector
4. Battery charge level indicator
5. Signal strength indicator
6. Charger connector



During synchronization, one of the 775 channels is automatically selected. To save battery, it is recommended to disconnect equipment in the end of the tour



the_crystal_sound

thecrystalsound2014

thecrystalsound

Tallinn +372 880 13 74
estonia@crystal-sound.com

Vilnius +370 521 408 77
lithuania@crystal-sound.com

Riga +371 665 55 007
latvia@crystal-sound.com

Barcelona +34 932 202 706
spain@crystal-sound.com

Moscow +7 925 235 47 05
hello@crystal-sound.com

Saint-Petersburg +7 812 300 05 15 (techsupport)
+7 812 608 50 15 (head office Russia)
hello@crystal-sound.com




Instruction DCS-210



SYNCHRONIZATION

Performed when the earphones / microphone are disconnected



Holding button  bring the transmitter to the receiver



When Synchronization is successful, the backlight turns on

TO SWITCH ON / SWITCH OFF



To switch on the device, connect the earphone / microphone to the receiver / transmitter



To switch off the device, remove earphone / microphone



If there no signal from the transmitter for more than 3 minutes, the receiver will be automatically switched off

THE SIGNAL LEVEL



There is signal



The connection was lost

BATTERY CHARGE



Connect the charge to the device. When the device is fully charged the green LED will be lit up




To charge several devices at the same time, use special equipment




To be fully charged from 0 to 100% it will take 2.5 hours. The operating time of the transmitter is 60 hours, the receiver 100 hours

MICROPHONE MUTE





To switch off
Hold the button  for 1-2 seconds until red LED is lit up





To switch on
Hold the button  for 1-2 seconds until red LED is turned off

BUILT-IN MICROPHONE



To switch on
Hold on buttons  at the same moment  for 3-5 sec until the green LED is lit up



To switch off
Hold on buttons  at the same moment  for 3-5 sec until the green LED is turned off



The transmitter is able to work without connecting an external microphone